

M-TEK L-BRACKET WALL MOUNTING



CSR




FIG 1 | SYSTEM ASSEMBLY

SYSTEM ASSEMBLY

STAGE 1 - L-BRACKET ASSEMBLY

Secure the L-BKT ① to the wall using two M8x60mm concrete bolts.

Ensure that the L-BKT ① is at least 150mm from the top of the wall.

Connect the Tongue ② to the L-BKT ① using the supplied M12x40mm bolt and M12 nut.

Ensure that the groove on the Tongue ② is facing downwards. See Fig 5.

STAGE 2 - M-TEK POST

Loosen the Post U-Bolt and rest the M-TEK Post ③ on the M-TEK Tongue with the Rail Clamps facing inwards.

Slide the Post U-Bolt under the groove on the Linking Bracket. See Fig 4. Tighten the Post U-Bolt nuts.

STAGE 3 - SPACING

Repeat “L-Bracket Assembly” and “M-TEK Post” stages ensuring the distance between post centres does not exceed 3.0 metres.

STAGE 4 - RAILS

Attach bottom, middle and top rails ④ to the M-TEK Post.

Continuous Rail Linkage - See Fig 2. Use Rail Clamps on M-TEK Post.

Angled Rail Linkage Joggle or Chain Joggle – See Fig 3 & 4. Use Joggle to link and clamp rails at a corner or cross junction.

Rails must overlap at least 100mm on each side of the clamp.

Ensure that all bolts are tight before use.




FIG 2 | CONTINUOUS RAILS




FIG 3 | LINKAGE JOGGLE




FIG 4 | CHAIN JOGGLE

1300 377 233

www.csrroofing.com.au

TopCat Safety Rail is a division of CSR Building Products Ltd. ABN 55008631356. Chatswood NSW 2067.